

BMW Motorrad

Maintenance schedule

R 1150 GS / R 1150 GS EVO / R 1150 GS Adventure



Customer	Licence No.	Odometer reading	BMW Inspection at 1,000 km/600 miles	BMW Maintenance Service every 10,000 km/6,000 miles	BMW Inspection every 20,000 km/12,000 miles	BMW Annual Service
Job Order No.	Date	Mechanic's signature				
Use BMW MoDiTeC to read stored error codes from fault memory			☐	☐	☐	☐
Change engine oil, warmed to normal operating temperature, replace oil filter if used exclusively in short-distance operation, or at outside temperatures below 0 °C (32 °F), no later than every 3 months, or every 3,000 km/1,800 miles ^{*)}			☐	☐	☐	☐
Change oil in gearbox, warmed to normal operating temperature no later than every 2 years ^{*)}					☐	☒
Change final-drive lubricant, warmed to normal operating temperature every 40,000 km/25,000 miles, or no later than every 2 years ^{*)}			☐		☒	☒
Replace fuel filter ^{*)} In normal operating conditions every 40,000 km/25,000 miles, if fuel quality is poor every 20,000 km/12,000 miles					☒	
Check battery electrolyte level, top up with distilled water as necessary Battery terminals, clean and grease as necessary					☐	☐
Replace intake air filter element Replace air filter every 10,000 km/6,000 miles if vehicle is exposed to high levels of dirt and dust, or more frequently if necessary ^{*)}				☒	☐	
Check brake fluid level at front and rear				☐	☐	
Check operation of brake system, inspect for leaks; repair/replace as necessary ^{*)}					☐	
Check brake pads and discs for wear, replace as necessary ^{*)}				☐	☐	
Change brake fluid annually						☐
Check clutch fluid level				☐	☐	
Change clutch fluid ^{*)} every 2 years at the latest						☒
Check security of rear-wheel securing screws			☐			
Check rear wheel bearing play by tilting wheel					☐	
Check swinging arm bearings (no play), adjust as necessary ^{*)}			☐		☐	
Check operation of side stand switch			☐	☐	☐	☐
Grease side stand pivot			☐	☐	☐	
Tension poly-V belt Retension new poly-V belt once at 10,000 km/6,000 miles				☒		
Replace poly-V belt ^{*)} Replace poly-V belt every 60,000 km/35,000 miles					☒	
Inspect spark plugs				☐		
Replace spark plugs					☐	
Check security of cylinder-head fasteners			☐			
Check valve clearance and adjust as necessary			☐	☐	☐	
Check ease of movement of throttle cable, check for chafing and kinks, replace as necessary ^{*)} Check Bowden cable play Check synchronisation, adjust as necessary			☐	☐	☐	
Final inspection with road safety and operation check – Condition of tyres, rims and spokes, tyre pressures – Clutch, shift mechanism, hand and foot brakes, steering – Lighting and signal indicators, warning and indicator lamps, instruments – Optional equipment – Road test as necessary			☐	☐	☐	☐

^{*)} Write up on separate invoice; ☐ Not part of standard service procedure

